



Garmin Nuvi 2455LMT Battery Replacement

This guide shows how to replace the battery in the Garmin Nuvi 2455LMT

Written By: Torrance Williams



INTRODUCTION


This battery is a simple part to replace and will only take about 2-3 minutes. This guide requires a metal spudger and the Torx 4 screwdriver.



TOOLS:


- [iFixit Opening Tools](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Battery




- Remove the orange band from the motherboard to access screws.

Step 2




- Unscrew the motherboard from the device
- Lift the motherboard to reveal the cords underneath.

Step 3



- Find the cord that connects the motherboard to the battery
- Disconnect this cord from the motherboard

Step 4



- Using the plastic opening tool, pry the battery from the base of the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 01:05:21 AM.